FloorStore Direct
Online Flooring

UV OILED ENGINEERED WOOD FLOORING

Cleaning & Maintenance Guide

UV Oiled finishes provide a beautiful, natural matte appearance that highlights the texture of the wood grain. Unlike traditional lacquers, UV Oil penetrates the wood, requiring specific care to maintain its protective properties and luster. Following this guide will ensure your floor remains in peak condition for a lifetime.

1. Daily Maintenance with Pallmann Clean

For regular cleaning, it is essential to use a pH-neutral solution that removes dirt without stripping the natural oils from the wood surface.

- **Pallmann Clean:** A highly concentrated, pH-neutral cleaner. Mix approximately 50ml per 5 litres of water.
- **Preparation:** Always sweep or vacuum the floor first to remove grit and abrasive particles that can cause micro-scratches.
- **Application:** Use the **Dada Spin Mop** to apply the solution. The floor should be touch-dry within minutes.

The Dada Spin Mop Advantage:

Wood is sensitive to excessive moisture. Traditional mops often saturate the floor, which can lead to swelling or "cupping" of engineered boards. The **Dada Spin Mop** features a high-speed centrifugal wringer that allows you to control the dampness perfectly. For wood floors, the mop head should be "barely damp"—never dripping.

2. Periodic Care with Pallmann Magic Oil Care

UV Oiled floors require periodic refreshment to replenish the oil in the surface fibers. This prevents the floor from looking "thirsty" or dull.

- **Pallmann Magic Oil Care:** Use this every 2-3 months (or more frequently in high-traffic areas).
- **Protection:** It adds a dirt-repellent protective film and a refreshed matte appearance.
- **Mixing:** Dilute 100ml to 250ml of Magic Oil Care in 5 litres of water and mop the floor as usual. No buffing is required.

> ⚠️ **STRICTLY NO STEAM CLEANERS**
>
> Under no circumstances should a steam cleaner be used on UV Oiled engineered wood. The high-pressure steam forces moisture deep into the wood grain and between the lamella layers, causing irreversible structural damage, delamination, and whitening of the oil finish. **Use of steam cleaners will void your Floorstore Direct warranty.**

3. Long-Term Protection

- **Furniture Protection:** Attach high-quality felt pads to all furniture legs. Avoid dragging heavy items across the floor; always lift and place.
- **Entry Mats:** Use heavy-duty walk-off mats at all external doors to collect grit, salt, and moisture.
- **Spills:** Wipe up any liquid spills immediately. UV Oil is water-resistant but not waterproof; standing liquids can cause spotting if left too long.